



## THERMOBOX® F

With efficient convection heating and hot-air fans to maintain a uniform temperature throughout the box. The flow of hot air forms a buffer around the food, which compensates for undesirable heat losses. The temperature is easy to adjust to the desired level and can be read via a digital control unit.

The interior is made entirely of stainless steel with pressed guides and no joints. Insulated with polyurethane, which expands under high pressure and combines the outer and inner containers to form a strong and well insulated unit.

F boxes are ideal for storing hot food where the quality of the food is maintained during transport.



## TECHNICAL SPECIFICATIONS

**Exterior walls:** ABS plastic.

**Inner container:** Welded container in stainless steel.

**Guides:** Stainless steel, pressed from the inner container.

**Insulation:** Polyurethane foam.

**Door:** Internal surface made of smooth and seamless stainless steel. Exterior in ABS plastic.

**Wheels:** Hot-dip galvanized steel. 160 mm wheels with rubber tires, two braked and two fixed.


**Top frame:** Stainless steel and PVC corners.


**Trolley frame:** Reject list of galvanized steel coated with PVC.


**F:** Efficient convection heating system, with electronic temperature control, insulation class IP 44, 230V/1000W. CE and S mark.


## THERMOBOX® F – CONVECTION HEATING

Convection heat with added value and many benefits! Short heating time, Hot air fan to compensate temperature losses, Flexible heating cabinet.

F90	GUIDES	OUTER	INNER	WEIGHT
	6 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1055mm	W: 330mm D: 540mm H: 508mm	54 kg
	230V/550W <b>Product number:</b> 122004-ZF SDX Thermobox F90 (6 GN 1/1) Single handed grip handle  <b>Product number:</b> 122004-XF SDX Thermobox F90 (6 GN 1/1) Excenter lock			

F120	GUIDES	OUTER	INNER	WEIGHT
	8 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1215mm	W: 330mm D: 540mm H: 668mm	57 kg
	230V/550W <b>Product number:</b> 122027-ZF SDX Thermobox F120 (8 GN 1/1) Single handed grip handle  <b>Product number:</b> 122027-XF SDX Thermobox F120 (8 GN 1/1) Excenter lock			

F150	GUIDES	OUTER	INNER	WEIGHT
	10 x GN 1/1 80mm spacing	W: 525mm D: 770mm H: 1180mm	W: 330mm D: 540mm H: 828mm	61 kg
	230V/1000W <b>Product number:</b> 122064-ZF SDX Thermobox F150 (10 GN 1/1) Single handed grip handle  <b>Product number:</b> 122064-XF SDX Thermobox F150 (10 GN 1/1) Excenter lock			

F180	GUIDES	OUTER	INNER	WEIGHT
	12 x GN 1/1 80mm spacing	W: 525mm D: 770mm H: 1355mm	W: 330mm D: 540mm H: 1000mm	65 kg
	230V/1000W <b>Product number:</b> 122033-ZF SDX Thermobox F180 (12 GN 1/1) Single handed grip handle  <b>Product number:</b> 122033-XF SDX Thermobox F180 (12 GN 1/1) Excenter lock			

6


8


10


12


## THERMOBOX® F – CONVECTION HEATING

Convection heat with added value and many benefits! Short heating time. Hot air fan to compensate temperature losses. Flexible heating cabinet.

	GUIDES	OUTER	INNER	WEIGHT
	6+6 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1445mm	W: 330mm D: 540mm H: 508+508mm	65 kg
	2x230V/550W <b>Product number:</b> 122134-ZF SDX Thermobox FF180 (6+6 GN 1/1) Single handed grip handle  <b>Product number:</b> 122134-XF SDX Thermobox FF180 (6+6 GN 1/1) Excenter lock			

	GUIDES	OUTER	INNER	WEIGHT
	14 x GN 1/1 80mm spacing	W: 525mm D: 770mm H: 1515mm	W: 330mm D: 540mm H: 1160mm	70 kg
	230V/1000W <b>Product number:</b> 122070-ZF SDX Thermobox F210 (14 GN 1/1) Single handed grip handle <i>Additional pull handles on the sides, at the back, are included</i>  <b>Product number:</b> 122070-XF SDX Thermobox F210 (14 GN 1/1) Excenter lock <i>Additional pull handles on the sides, at the back, are included</i>			

	GUIDES	OUTER	INNER	WEIGHT
	8+6 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1605mm	W: 330mm D: 540mm H: 668+508mm	70 kg
	2 x 230V/550W <b>Product number:</b> 122135-ZF SDX Thermobox FF210 (8+6 GN 1/1) Single handed grip handle <i>Additional pull handles on the sides, at the back, are included</i>  <b>Product number:</b> 122135-XF SDX Thermobox FF210 (8+6 GN 1/1) Excenter lock <i>Additional pull handles on the sides, at the back, are included</i>			

	GUIDES	OUTER	INNER	WEIGHT
	8+8 x GN 1/1 80mm spacing	W: 920mm D: 750mm H: 1215mm	W: 330+330mm D: 540mm H: 668+668mm	110 kg
	2 x 230V/550W <b>Product number:</b> 122132-ZF SDX Thermobox FF240 (8+8 GN 1/1) Single handed grip handle			

6  
6


14

6  
8


8  
8

## THERMOBOX® F – CONVECTION HEATING


Convection heat with added value and many benefits! Short heating time, Hot air fan to compensate temperature losses, Flexible heating cabinet.

	GUIDES	OUTER	INNER	WEIGHT
	12+12 x GN 1/1 80mm spacing	W: 920mm D: 770mm H: 1355mm	W: 330+330mm D: 540mm H: 1000mm	130 kg
	2 x 230V/1000W <b>Product number:</b> 122048-ZF SDX Thermobox FF360 (12+12 GN 1/1) Single handed grip handle			

12 | 12

	GUIDES	OUTER	INNER	WEIGHT
	14+14 x GN 1/1 80mm spacing	W: 920mm D: 770mm H: 1515mm	W: 330+330mm D: 540mm H: 1160mm	140 kg
	2 x 230V/1000W <b>Product number:</b> 122057-ZF SDX Thermobox FF420 (14+14 GN 1/1) Single handed grip handle			

14 | 14

	GUIDES	OUTER	INNER	WEIGHT
	12+12+12 x GN 1/1 80mm spacing	W: 1330mm D: 770mm H: 1355mm	W: 330+330+330mm D: 540mm H: 1000mm	195 kg
	3 x 230V/1000W <b>Product number:</b> 122136-ZF SDX Thermobox FFF540 (12+12+12 GN 1/1) Single handed grip handle			

12 | 12 | 12