



THERMOBOX® K

Equipped with efficient forced-air cooling, which cools the box more rapidly. A cold-air fan ensures a uniform temperature throughout the box. The cold-air supply forms a cold buffer around the food, which eliminates undesirable temperature increases. The temperature is easy to adjust to the desired level and can be read via a digital control unit.

The interior is made entirely of stainless steel with pressed guides and no joints. Insulated with polyurethane, which expands under high pressure and combines the outer and inner containers to form a strong and well insulated unit.

K boxes are ideal for food that is to be served cold as well as for transporting and storing food that is to be heated at a later stage in the process.



TECHNICAL SPECIFICATIONS

Exterior walls: ABS plastic.

Inner container: Welded container in stainless steel.

Guides: Stainless steel, pressed from the inner container.

Insulation: Polyurethane foam.

Door: Internal surface made of smooth and seamless stainless steel. Exterior in ABS plastic.


Wheels: Hot-dip galvanized steel. 160 mm wheels with rubber tires, two braked and two fixed. CCC540 box has six wheels, two braked and four fixed.


Top frame: Stainless steel and PVC corners.


Trolley frame: Reject list of galvanized steel coated with PVC.


K: Efficient compressor cooling with electronic temperature control 230V/245W, insulation class IP44.

THERMOBOX® K – COMPRESSOR COOLING

K90	GUIDES	OUTER	INNER	WEIGHT
	6 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1115mm	B: 330mm D: 540mm H: 508mm	80 kg
	<p>Product number: 122207-ZK SDX Thermobox K90 (6 GN 1/1) Single handed grip handle</p> <p>Product number: 122207-XK SDX Thermobox K90 (6 GN 1/1) Excenter lock</p>			

K120	GUIDES	OUTER	INNER	WEIGHT
	8 x GN 1/1 80mm spacing	W: 525mm D: 750mm H: 1275mm	W: 330mm D: 540mm H: 668mm	85 kg
	<p>Product number: 122205-ZK SDX Thermobox K120 (8 GN 1/1) Single handed grip handle</p> <p>Product number: 122205-XK SDX Thermobox K120 (8 GN 1/1) Excenter lock</p>			

K150	GUIDES	OUTER	INNER	WEIGHT
	10 x GN 1/1 80mm spacing	W: 525mm D: 770mm H: 1430mm	W: 330mm D: 540mm H: 825mm	90 kg
	<p>Product number: 122208-ZK SDX Thermobox K150 (10 GN 1/1) Single handed grip handle</p> <p>Product number: 122208-XK SDX Thermobox K150 (10 GN 1/1) Excenter lock</p>			

K180	GUIDES	OUTER	INNER	WEIGHT
	12 x GN 1/1 80mm spacing	W: 525mm D: 770mm H: 1605mm	W: 330mm D: 540mm H: 1000mm	95 kg
	<p>Product number: 122270-ZK SDX Thermobox K180 (12 GN 1/1) Single handed grip handle</p> <p>Product number: 122270-XK SDX Thermobox K180 (12 GN 1/1) Excenter lock</p>			

6

8

10

12