



Page Catalog : 80

Electric stoves 4 plates aligned with the top, on open cupboard

E7/4SPA7

Fourneaux

Descriptions

mm (W x D x H)	700 x 700(730) x 850/920
kW	10
gross Weight (Kg)	92 kg
Voltage	400-230/3N 50-60Hz
Volume (m ³)	0.8 m ³

Product details

- 4 plates 300x300 mm, independent (4x 2,5 kW).
- Made of stainless steel AISI 304, stainless steel adjustable feet.
- Top (15/10 mm) in stainless steel AISI 304.
- Rear chimney in stainless steel AISI 304.
- Cooking top, watertight "IPX4".
- Cast iron plates of high thickness (h.40 mm) "flush", with safety device in case of overheating.
- Regulation by means of a 7-position switch (each hearth), with pilot light, front access for easy maintenance.

The +

ADVANTAGE:

- Plates with rapid temperature rise
- Keeps the plates in operation, even without use (without container)
- Easy maintenance, with a recovery drawer, front access
- Plates aligned to the cooking surface, easy transfer from pans, frying pans, pots, etc. no more

efforts, no need to lift anymore !

PLUS:

Arrangement possibilities 700+700 "BACK to BACK" or in combination with the new line OPTIMA 900 700+900. Stainless steel upper Top AISI 304 with thickness of 15/10 front edge with drain gutter, pressed-in and waterproof planes, internal angles of rounded tanks, quality components "High Technology".....A perfect finish, attention to detail, superb design and a perfect alignment and an easy "HEAD to HEAD" module connection.