

**PROMO**

## Ventilated "back bar" bottle cooler, 2 sliding glass doors

**WR-TAB2-S3**

### Descriptions

<b>mm (W x D x H)</b>	900 x 520 x 900
<b>T°</b>	+1° +10°
<b>kW</b>	0.23
<b>Voltage</b>	230/1N 50HZ
<b>gross Weight (Kg)</b>	73 kg
<b>Volume (m<sup>3</sup>)</b>	0.54 m <sup>3</sup>

Page Promo : **47-Div25**

### Product details

- Energy class: B.
- Noise level: 60 dB(A).
- Interior volume: 201 liters.
- Interior dimensions: 820x420xh750 mm.
- Load capacity: 150 cans (33 cl) or 208 bottles (33 cl).
- 2 sliding doors (self-closing) with locking device for loading
- Supplied with: 4 shelves.
  
- Low energy consumption components.
- Glass door(s), double glazing "Thermopane®", automatic closing.
- Key lock closure device.
- Horizontal LED interior lighting.
- Supplied with: 2 removable and adjustable-height shelves per door.
- Built-in compressor unit, climate class 4 (30°C & 55% RH).
- Refrigerant gas R600a.
- Electronic regulation, digital temperature display +1° to +10°C.
- Ventilated evaporator.

- Automatic defrost with condensate auto-evaporation.
- Exterior made of lacquered steel sheet, black color.
- Interior made of embossed aluminum.
- Polyurethane insulation (40 mm) without CFCs.
- Adjustable lower leveling feet.
- Appliance built in compliance with all applicable (CE) standards.